

UpgradeTool Operation Manual

1. To find UpgradeTool in the CD and install it, then run it, see below picture:



2.Click "IP Search", select the DVR's IP address and port, then click "Browse", see below pictures:







3.To Browse the Logo(bmp), see below pic:



Then click "Upgrade", finally you will see Upgrade successful, at the same time the dvr is rebooting and you can see your LOGO now like below pictures:





Pls Note: New version upgrade process is the same as Logo upgrade.